Spare Parts Catalogue

Version: 2009/01/15a EN

alber

scalamobil iQ

General Information

For any order of spare parts the following information is required:

- *Product type*
- *Product name & model*
- *Serial Number*
- *Part-Number*
- *Part-Description*

Exploded view drawings and code numbers are not contractual and subject to modification, in relation to Invacare® continous product improvement policy to meet end users needs.

The reproduction or use of this work, or of any substantial part of this work, in any form or by any electronic, mechanical or other means, including photocopying, scanning and recording, and in any information storage and retrieval system, including electronic transmission, is forbidden without the prior written permission of Invacare® International Sarl.

TABLE OF CONTENTS

Drive unit complete scalamobil S30

Drive unit complete scalamobil S30 5
Drive unit scalamobil S30 spare-parts 6
Battery pack 2 x 3.4 Ah scalamobil S30 7
Electronic box scalamobil S30 complete, 3.4 Ah 8
Case for battery pack scalamobil S30with spiral cable 9
Outer wheel scalamobil S30, complete 10
Brake scalamobil S30/S31/S34 right complete 11
Brake scalamobil S30/S31/S34 left complete 12

Handlebar scalamobil S30

Handlebar scalamobil S30 13
Handlebar scalamobil S30 spare-parts 14

Seat unit and footrest scalamobil S31completely mounted

Seat unit and footrest scalamobil S31completely mounted 15
Seat unit and footrest scalamobil S31 spare-parts 16

Battery charger scalamobil 0,5 A (BC24005LA)

Battery charger scalamobil 0,5 A (BC24005LA) 17

Programming key scalamobil S30

Programming key scalamobil S30 18

User manual scalamobil S30 IQ

User manual scalamobil S30 IQ 19

Drive unit complete scalamobil S30



number	Description	Valid from → until	Qty
	Drive unit scalamobil S30 spare-parts		
1464436	Drive unit complete scalamobil S30		1

Drive unit scalamobil S30 spare-parts



number	Description	Valid from → until	Qty
	Battery pack 2 x 3.4 Ah scalamobil S30		1
	Electronic box scalamobil S30 complete, 3.4 Ah		1
	Case for battery pack scalamobil S30with spiral cable		1
1461655	Cover scalamobil S30 for side shell		1
1456789	Distance socket scalamobil S30 for lower mounting		1
1457310	Lower bolt scalamobil S30 340 mm		1
1456888	Plastic sticker for stairs protectionfor scalamobil S30		1
1456873	Screws and bolts for mounting of upper bolts scalamobil S30 (without bolts)		1
1463454	Device feet scalamobil S30		1
1456185	Locking ring 14 x 1		1
1456854	Set collar galvanized for scalamobil		1
1457209	Bolts scalamobil 100 mm		1
	Outer wheel scalamobil S30, complete		1

Battery pack 2 x 3.4 Ah scalamobil S30



number	Description	Valid from → until	Qty
1456874	Housing battery pack for scalamobil S30 with circuit board		1
1456799	Batteries scalamobil S30/S31/S34 complete		1
1456875	Locking mechanism battery pack scalamobil S30		1
1456389	Fuse 15 A		1
1461746	Circuit board for batteries complete assembled		1

Electronic box scalamobil S30 complete, 3.4 Ah



number	Description	Valid from → until	Qty
1457334	Circuit board scalacombi S31 without sensors		1
1457281	Circuit board scalamobil S30 IQ, with bearing sensor		1
1456889	Housing electronic box scalamobil S30 IQ		1
1456876	Cover for electronic box scalamobil S30		1
1461741	Sticker "Operating cover" scalamobil S30 IQ		1
1461855	Sticker "Operating cover" scalacombi S31		1

Case for battery pack scalamobil S30with spiral cable



number	Description	Valid from → until	Qty
1461704	Case for battery pack scalamobil S30		1
1456798	Control cable / motor connection S30		1
1456890	Handle shell with sticker		1
1456877	Carrying handle scalamobil S30		1
1456796	Sticker on handle shell scalamobil IQ		1

Outer wheel scalamobil S30, complete



number	Description	Valid from → until	Qty
1456806	Magnet holder scalamobil S30		1
1467005	Eccentric plate left/right for wheel outside		1
1467006	Eccentric plate for left wheel inside		1
1467007	Eccentric plate for right wheel inside		1
1456793	Rim, inner wheel scalamobil S30 (shiny version until 07/2008) *replaced by 1490208*	→ 20080731	1
1490208	Rim, inner wheel scalamobil S30/S31/S34 (beamless version from 08/2008) *replaces 1456793*	20080801 →	1
1456792	Tyre for scalamobil S30/S31/S34		1
1456878	Rim, outer wheel scalamobil S30 (shiny version until 07/2008) *replaced by 1490209*	→ 20080731	1
1490209	Rim, outer wheel scalamobil S30/S31/S34 (beamless version from 08/2008) *replaces 1456878*	20080801 →	1
1463684	Screw for rim - M 4 x 18		1
1456879	Hub cover S30 (shiny version until 07/2008) *replaced by 1490058*	→ 20080731	1
1490058	Hub cover S30/S31/S34 (beamless version from 08/2008) *replaces 1456879*	20080801 →	1
1463683	Screw hubcap - M 3 x 8		1
1457279	Brake scalamobil S30/S31/S34 right complete		1
1457278	Brake scalamobil S30/S31/S34 left complete		1
	Brake scalamobil S30/S31/S34 right complete		1
	Brake scalamobil S30/S31/S34 left complete		1

Brake scalamobil S30/S31/S34 right complete



number	Description	Valid from → until	Qty
1456417	Tension spring brake		1
1456794	Brake lining scalamobil S30		1
1456880	Braking wheel scalamobil S30		1

Brake scalamobil S30/S31/S34 left complete



number	Description	Valid from → until	Qty
1456417	Tension spring brake		1
1456794	Brake lining scalamobil S30		1
1456880	Braking wheel scalamobil S30		1

Handlebar scalamobil S30



number	Description	Valid from → until	Qty
	Handlebar scalamobil S30 spare-parts		
1457283	Handlebar scalamobil S30		1
1456803	H-part with standpipes scalamobil S30		1
1461818	H-part scalamobil S30		1
1464449	Handlebar scalacombi S31		1

Handlebar scalamobil S30 spare-parts



number	Description	Valid from → until	Qty
1457283	Handlebar scalamobil S30		1
1456883	Main switch for scalamobil S30		1
1456804	Control button for scalamobil right pre-assembled		1
1456886	Handle for scalamobil S30 right hand side		1
1456884	LED display element for scalamobil S30		1
1456892	Covering bar scalamobil S30 (with stoppers)		1
1456882	Set of stoppers for gripping loops scalamobil S30		1
1456791	Sticker "scalamobil IQ" on covering bar		1
1456809	Sticker on covering bar ,scalamobil		1
1456416	Adjustment knob scalamobil		1
1456801	Distance spacer for lateral adjustment scalamobil S30		1
1456800	Collar for adjustment knob scalamobil S30		1
1456891	Adjustment knob bottom part for scalamobil S30 RAL 7038		1
1456797	Spiral cable scalamobil S30		1
1456887	Handle for scalamobil S30 left hand side		1
1456805	Cover "alber" for handle scalamobil S30		1
1456885	direction switch S30 (left hand side)		1
1456881	Set of stoppers for handles scalamobil S30		1
1456802	Lock for horizontal adjustment		1
1461765	Circuit board Start/Stop S30		1
1461766	Circuit board for direction control S30		1

Seat unit and footrest scalamobil S31completely mounted



number	Description	Valid from → until	Qty
	Seat unit and footrest scalamobil S31 spare-parts		
1464513	Seat unit and footrest scalamobil S31completely mounted		1

Seat unit and footrest scalamobil S31 spare-parts



number	Description	Valid from → until	Qty
1457336	Armrest right for scalacombi S31		1
1456807	Seat plate scalacombi S31/S34		1
1457335	Armrest left for scalacombi S31		1
1457337	Backrest with cover scalacombi S31		1
1461838	Footrest for scalacombi S31		1
1456808	Quickpin, quick release bolt for footrest		1
1456453	Steering wheels S31/X7		1

Battery charger scalamobil 0,5 A (BC24005LA)



number	Description	Valid from → until	Qty
1489340	Battery charger scalamobil 0,5 A (BC24005LA)		1

Programming key scalamobil S30



number	Description	Valid from → until	Qty
1456795	Programming key scalamobil S30		1

User manual scalamobil S30 IQ





number	Description	Valid from → until	Qty
1456449	User manual scalamobil S30 IQ		1
1456450	Therapeutic information scalamobil S30 IQ		1

EN

Belgium & Luxemburg:
Invacare nv, Autobaan 22, B-8210 Loppem
Tel: (32) (0)50 83 10 10, Fax: (32) (0)50 83 10 11
Belgium@invacare.com
Danmark:
Invacare A/S, Sdr. Ringvej 37, DK-2605 Brøndby
Tel: (45) (0)36 90 00 00, Fax: (45) (0)36 90 00 01
Denmark@invacare.com
Germany
Ulrich Alber GmbH, Vor dem Weissen Stein 21, D-72461 Albstadt-Tailfingen
Tel: (49) (0)7432 2006 0, Fax: (49) (0)7432 2006 299
Info@ulrich-alber.de
España:
Invacare SA, c/Areny s/n, Polígon Industrial de Celrà, E-17460 Celrà (Girona)
Tel: (34) (0)972 49 32 00, Fax: (34) (0)972 49 32 20
Contactsp@invacare.com
France:
Invacare Poirier SAS, Route de St Roch, F-37230 Fondettes
Tel: (33) (0)2 47 62 64 66, Fax: (33) (0)2 47 42 12 24
Contactfr@invacare.com
Ireland:
Invacare Ireland Ltd, Unit 5 Seatown Business Campus, Seatown Road, Swords, County Dublin - Ireland
Tel: (353) 1 810 7084, Fax: (353) 1 810 7085
ireland@invacare.com
Italia:
Invacare Mecc San s.r.l., Via dei Pini 62, I-36016 Thiene (VI)
Tel: (39) 0445 38 00 59, Fax: (39) 0445 38 00 34
Italia@invacare.com
Nederland:
Invacare BV, Celsiusstraat 46, NL-6716 BZ Ede
Tel: (31) (0)318 695 757, Fax: (31) (0)318 695 758
nederland@invacare.com
Norge:
Invacare AS, Grensesvingen 9, Postboks 6230, Etterstad, N-0603 Oslo
Tel: (47) (0)22 57 95 00, Fax: (47) (0)22 57 95 01
norway@invacare.com island@invacare.com
Österreich:
Mobitec Mobilitätshilfen GmbH, Herzog Odilostrasse 101, A-5310 Mondsee
Tel: (43) 6232 5535 0, Fax: (43) 6232 5535 4
office@mobitec-austria.com, austria@invacare.com
Portugal:
Invacare Lda, Rua Estrada Velha, 949, P-4465-784 Leça do Balio
Tel: (351) (0)225 1059 46/47, Fax: (351) (0)225 1057 39
Portugal@invacare.com
Sverige & Suomi:
Invacare AB, Fagerstagatan 9, S-163 91 Spånga
Tel: (46) (0)8 761 70 90, Fax: (46) (0)8 761 81 08
sweden@invacare.com
Finland@invacare.com
Switzerland:
Mobitec Rehab AG, Benkenstrasse 260, CH-4108 Witterswil
Tel: (41) (0)61 487 70 80, Fax: (41) (0)61 487 70 81
office@mobitec-rehab.ch
switzerland@invacare.com
United Kingdom:
Invacare Limited, Pencoed Technology Park, Pencoed, Bridgend CF35 5HZ
Switchboard Tel: (44) (0)1656 776200, Fax: (44) (0)1656 776201
Customer services Tel: (44) (0)1656 776222, Fax: (44) (0)1656 776220
UK@invacare.com

© Ulrich Alber, Albstadt . All Rights Reserved.